



Fiery options Help (server)

© 2024 Fiery, LLC. The information in this publication is covered under Legal Notices for this product.

27 August 2024

Contents

Managing licenses for Fiery options on server	5
Managing licenses	5
Configure a proxy server	5
Accessing the Manage Fiery Options page	6
License notifications	6
Activating a Fiery option	6
Activate a Fiery option automatically	7
Activating consecutive License Activation Codes (LACs)	7
Activate a temporary license automatically	8
Activate a Fiery option manually	9
Restoring an activated Fiery option	10
Restore Fiery options automatically	10
Restore Fiery options manually	10
Back up license activation codes	11
Troubleshoot Fiery options	11
Activation generates an error message	11
Incorrect system clock settings	12
Error messages	12

Managing licenses for Fiery options on server

You can manage licenses for Fiery server-based options on Fiery servers such as Fiery Automation Package, Fiery ColorRight Package, Fiery Graphic Arts Pro Package, or Fiery Hot Folders/Virtual Printers.

For information on managing licenses for Fiery client-based options such as Fiery Compose, Fiery Impose, Fiery JobMaster, Fiery JobFlow, or Adobe Acrobat kits, see [Managing licenses for Fiery options on client computers](#).

To use a Fiery option installed on the Fiery server, you must first obtain a unique License Activation Code (LAC) and then activate the license.

Obtaining licenses

You can obtain a license for a Fiery option from your Fiery dealer, the printer manufacturer, or the [Fiery Shop](#).

After obtaining a license, you can perform the following tasks:

- [Activate a Fiery option](#) on page 7
- [Restore an activated Fiery option](#) on page 10
- [Back up license activation codes](#) on page 11

You can activate and restore a Fiery option on the Manage Fiery Options page. For more information, see [Accessing the Manage Fiery Options page](#) on page 6.

Managing licenses

Managing licenses includes tasks such as activating and restoring Fiery options. The Fiery licensing server manages these License Activation Code (LAC) related tasks.

When you manage a license, the procedure depends on whether the Fiery server has an Internet connection.

- If the Fiery server is connected to the Internet, information is automatically transferred between the Fiery server and the Fiery licensing server.
- If the Fiery server is not connected to the Internet, you must manually transfer information between the Fiery server and the Fiery licensing server.

If your organization connects to the Internet through a proxy server, you must configure the proxy server settings.

Configure a proxy server

If the computer cannot find an Internet connection when it tries to connect to the licensing server, your organization might be using a proxy server to connect to the Internet. You can configure the proxy server settings and then proceed with licensing.

- 1 When you receive a message that says the computer does not have Internet access, click **Configure network setting**.
- 2 Type the requested values, and then click **Apply**.

Accessing the Manage Fiery Options page

The Manage Fiery Options page displays the Fiery options that are activated in addition to those that are available to be activated. You can access the Manage Fiery Options page in any of the following ways:

- Command WorkStation - In Device Center, click **General** > **General Info**, and click **Manage**.
- WebTools - In the **Home** tab, click **Manage**.
- Fiery Option Package license notifications - Click the **Activate License** link. For more information, see [License notifications](#) on page 6.

The Manage Fiery Options page opens in your default web browser.

License notifications

Notifications are displayed when licenses of installed Fiery options approach their expiration date or have expired. Notifications of the approaching license expiration are displayed at intervals during the last 90, 60, 30, 15, and 10 days of the license validity period. Notifications appear daily during the last 10 days and after the license has expired. Notifications are displayed:

- In the upper-right corner of Command WorkStation Job Center.
- On the Fiery server listed in the Home tab of Command WorkStation.

Note: License notifications are available only for Fiery options installed on Fiery servers with Fiery system software FS400/400 Pro and later.

The following links are present on the notifications:

- **Activate License** - Opens the Manage Fiery Options page to activate the License Activation Code (LAC). Activate License appears during the last 90 days of the license validity period.
- **Learn more** - Opens the Managing licenses for Fiery options Help.
- More icon (three vertical dots) hides the selected notification until the next expiration interval. However, notifications appear daily during the last 10 days of the license validity period and after the license has expired.

Note: You can view the license expiration date of the Fiery option in Command WorkStation Device Center, the Home tab of WebTools, and the Manage Fiery Options page.

Activating a Fiery option

When you activate a Fiery option, make sure you record the following:

- ID of the Fiery server. On the Configuration page, you can find the ID under BIOS Setup. In Command WorkStation, you can find the ID in Device Center under Server Configuration on the General tab. Click **RIP** and look for the ID under BIOS Setup on the right.
- Name of the option
- License Activation Code (LAC)

To back up your LAC, see [Back up license activation codes](#) on page 11.

You can activate options automatically or manually, depending on whether the Fiery server you are activating the options on is connected to the Internet. For more information, see [Managing licenses](#) on page 5.

Activate a Fiery option automatically

You can activate a Fiery option automatically if the computer is connected to the Internet.

- 1 Open the Manage Fiery Options page. (See [Accessing the Manage Fiery Options page](#) on page 6.)
- 2 Click **Activate**, and then click **Continue** to agree to the terms and conditions of the license agreement.
- 3 Type the License Activation Code in the **License Activation Code** field, and then click **Continue**.
- 4 Click **Activate**.
- 5 If the activation requires a restart, you can click **Restart** to restart now or click **Finish** to activate additional options before restarting. If the activation does not require a restart, click **Finish**.

Activating consecutive License Activation Codes (LACs)

On Fiery options with a license validity period of 90 days or less, you can activate a new (consecutive) term license while simultaneously using the current term license. The current term license is active until expiration, after which the consecutive license seamlessly starts its term. This ensures that there is not a gap between the expiration of the current term license and the start of the consecutive term license.

You can activate a consecutive term license in the same manner as you have activated your current term license. For more information, see [Activate a Fiery option automatically](#) on page 7.

Additional information

- Consecutive term licenses can be activated only for Fiery options installed on Fiery servers with Fiery system software FS400/400 Pro and later.
- The Fiery server must be connected to the Internet to activate a consecutive term license.
- Notifications of license expiration are displayed at intervals of 90, 60, 30, 15, 10 days, and daily after 10 days. The consecutive term license can be activated anytime after the ninetieth (90th) day notification is displayed.

- You can utilize the full term of your current license even after activating the consecutive term license. The validity period of the consecutive term license will commence only after the expiration of the current term license.
- If a trial license is currently active, you can simultaneously activate a consecutive term license, but the validity period of the consecutive term license will commence only after the expiration of the trial license.
- If a consecutive term license is not activated before the expiration of the current term license, the Fiery option will be unavailable after the expiration date, and you will need to obtain a new license.

Activate a temporary license automatically

During the first installation of a Fiery option, if the Fiery licensing server is unavailable, you can continue to activate the Fiery option using a temporary license. You can activate a temporary license on the Manage Fiery Options page.

1 Access the Manage Fiery Options page in one of the following ways:

- In Command WorkStation Device Center, click **General** > **General Info**, and click **Manage**.
- In WebTools, in the **Home** tab, click **Manage**.

On the Manage Fiery Options page, if the License Activation Code (LAC) cannot be activated, a message is displayed that the license server is unavailable, and a temporary license can be activated.

2 Click the **Activate Temporary License** button.

3 Click **Restart**.

You can view the expiration date of the temporary license in Command WorkStation Device Center, the Home tab of WebTools, and on the Manage Fiery Options page.

Additional information

- The temporary license option is available only for Fiery options installed on Fiery servers with Fiery system software FS400/400 Pro and later.
- The Fiery server must be connected to the Internet to activate a temporary license.
- You can activate a temporary license only:
 - If the Fiery licensing server is unavailable.
 - During the first installation of the Fiery option.
- You cannot activate a temporary license if you reinstall the Fiery system software.
- A temporary license is valid only for 35 days. During this period, you can activate your License Activation Code (LAC).

Activate a Fiery option manually

If the computer is not connected to the Internet, you must manually transfer data between the computer and the Fiery licensing website to activate your license.

The first time you manually activate a license, the Fiery server interprets the activation as a request to restore any previously activated licenses. After going through the process to restore a license, you then repeat the process to activate a license, with some minor differences in the steps. See the two sections of the following procedure.

Create a request file for restoring a license

- 1 Open the Manage Fiery Options page. (See [Accessing the Manage Fiery Options page](#) on page 6.)
- 2 Click **Activate**.
- 3 Type the License Activation Code (LAC) in the **License Activation Code** field, and then click **Activate**.
- 4 Click **Continue** to proceed with the manual process.
- 5 Click **Create Request File** and save the file.
The name of the saved file will be similar to request-Restore-xxxxxxxx.dat.
- 6 Copy the request file to a computer that is connected to the Internet.
- 7 Open a browser and go to <https://licensing.fiery.com/>.
- 8 Click **Choose File**, select the request file, and then click **Upload Request File**.
- 9 Click **Download License File** and save the license file.
The name of the saved file will be similar to License-xxxxxxxx.dat.
- 10 Copy the license file to the computer where you first entered the License Activation Code.
- 11 Return to the **Generate License** window and click **Yes**.
- 12 Click **Choose File**, select and open the license file, and then click **Restore**.
- 13 Click **Finish**.

Create a request file for activating a license

- 14 Open the **Manage Fiery Options** page.
- 15 Click **Activate**.
- 16 Type the LAC in the **License Activation Code** field, and then click **Activate**.
- 17 Click **Continue** to proceed with the manual process.
- 18 Click **Create Request File** and save the file.
The name of the saved file will be similar to request-Activation-xxxxx-xxxxx-xxxxx-xxxxx.dat.
- 19 Copy the request file to a computer that is connected to the Internet.
- 20 Open a browser and go to <https://licensing.fiery.com/>.
- 21 Click **Choose File**, select the request file, and then click **Upload Request File**.

22 Click **Continue** and save the license file.

The name of the saved file will resemble License-xxxxx-xxxxx-xxxxx-xxxxx.dat.

23 Copy the license file to the computer where you first entered the License Activation Code.

24 Return to the **Generate License** window and click **Yes**.

25 Click **Choose File**, select and open the license file, and click **Activate**.

26 If the activation requires a restart, you can click **Restart** to restart now or click **Finish** to activate additional options before restarting. If the activation does not require a restart, click **Finish**.

Restoring an activated Fiery option

If previously activated options are unavailable and the computer cannot restore them by contacting the licensing server, you can use the Manage Fiery Options page to restore them.


Note: You can restore Fiery options only on Fiery servers with Fiery system software FS400/FS400 Pro and later.

You can restore options automatically or manually, depending on whether the computer is connected to the Internet. For more information, see [Managing licenses](#) on page 5.

Restore Fiery options automatically

You can restore previously activated Fiery options automatically if the computer is connected to the Internet.

1 Open the Manage Fiery Options page. (See [Accessing the Manage Fiery Options page](#) on page 6.)

2 Click the **Advanced Settings** icon () in the upper-right corner, and click **Restore**.


The Fiery option is restored.

3 Click **Finish**.

Restore Fiery options manually

If the computer is not connected to the Internet, you must manually transfer data between the computer and the Fiery licensing website. You will generate a request file, submit it to the Fiery licensing website to obtain a license file, and then use the license file to restore the options.

1 Open the Manage Fiery Options page. (See [Accessing the Manage Fiery Options page](#) on page 6.)

2 Click the **Advanced Settings** icon () in the upper-right corner, and click **Restore**.

3 Click **Continue** to proceed with the manual process.

4 Click **Create Request File** and save the file.

5 Copy the request file to a computer that is connected to the Internet.

- 6 Open a browser and go to licensing.fiery.com.
- 7 Click **Choose File**, select the request file, and then click **Upload Request File**.
A license file is generated.
- 8 Click **Download License File** and save the file.
- 9 Copy the license file to the computer where you are restoring options.
- 10 Return to the **Generate License** window and click **Yes**.
- 11 Click **Browse**, select and open the license file, and click **Restore**.

Back up license activation codes

You can back up your license activation codes to the Fiery IQ cloud.

Note: The backup license activation codes feature is available only with Fiery Command WorkStation 7.1 and later.


- 1 Click the cloud icon to open the **Fiery IQ cloud services manager** window.
- 2 Under **Backup license activation codes**, click the toggle button to start the backup.
Your license activation codes are backed up to the Fiery IQ cloud.
- 3 Click **View codes** to view your license activation codes.

Troubleshoot Fiery options

If problems occur when managing Fiery options, you can troubleshoot them.

Activation generates an error message

Error messages provide details about errors and suggest actions to take.

- 1 Check [Error messages](#) on page 12 for more information about the error. If the message guides you to contact technical support, you must first generate a diagnostic log file.
- 2 Open the Manage Fiery Options page to generate a diagnostic log file. (See [Accessing the Manage Fiery Options page](#) on page 6.)
- 3 Click the **Advanced Settings** icon () in the upper-right corner, and then click **Diagnostic Log** to generate a diagnostic log file.
- 4 When you contact technical support, provide the following information:
 - ID of the Fiery server. For more information, see [Activating a Fiery option](#) on page 7.
 - Name of option that you are trying to activate

- License Activation Code (LAC)
- Diagnostic log

Incorrect system clock settings

If the date and time settings on the system clock are incorrect, your computer may not connect with the Fiery licensing server. If this occurs, reset the clock on your computer.

Error messages

Error messages give you details about an error and suggest actions to take. Error messages appear in the license activation software and the Fiery licensing website.

For additional information or support, registered users may start a discussion through [Fiery Communities](#).

Message ID	Error message	Action
From the license activation software:		
OFA0020	The LAC is not in the correct format. Try entering the LAC again. Refer to the LAC card if you have one.	The License Activation Code (LAC) is not in the correct format. Try entering the LAC again. Refer to the LAC card if you have one.
OFA0010	The license file you selected is invalid, select a different one and try again.	During manual activation, you obtained a license file from the Fiery licensing website. Check that you selected the correct license file to upload. If the error still occurs, you can restore the Fiery options and try to activate them again.
OFA0090	Internal error. Please call Fiery technical support.	There is a problem with the license file. Try repeating the activation process from the beginning. If the error occurs again, restore the options and try to activate them again. If the error still occurs, contact technical support and provide the error code shown in the message.
OFA0060	Error <number> Proxy configuration is incorrect or proxy server is down.	An Internet connection could not be found. Check that the proxy settings are correct and try again. If the problem persists, contact your network administrator.
OFA0030	Internet connection could not be established.	An Internet connection could not be found. Check that the proxy settings are correct and try again. If the problem persists, contact your network administrator.

Message ID	Error message	Action
OFA0080	Error <number> Licensing session expired. Start licensing session again.	The license activation software was used in a different browser window more recently than this one. To continue, close this window and open a new one.
OFA00105	Error <number> The license activation software module is corrupted and Fiery system software must be reinstalled.	The license activation software module is corrupted, and the Fiery system software must be reinstalled. Contact technical support and provide the error code shown in the message.
OFA0070	Error <number> The license activation software module is corrupted. Reinstall Command WorkStation and try again.	Reinstall Command WorkStation and try again. On Windows, go to Control Panel > Add or Remove Programs and start Fiery User Software in maintenance mode. Select the Repair option and then select Command WorkStation. On Mac OS, use Fiery Software Uninstaller to uninstall Command WorkStation and then reinstall Command WorkStation.
OFA0050	Sorry we cannot deactivate the option requested. Please contact support for more information.	Try to restore Fiery options and deactivate them again. If the error still occurs, contact technical support.
OFA0040	Sorry we cannot reactivate the option requested. Contact support for more information.	Try to restore Fiery options and reactivate them again. If the error still occurs, contact technical support.
OFA00115	None of the options could be restored.	Previously activated licenses were not found for this computer. If you had licenses that were previously activated, contact technical support.
From the Fiery licensing server:		
EBIS0004	The LAC is not recognized. Check that you entered the correct LAC. Refer to the LAC card if you have one.	The LAC is not recognized. Check that you entered the correct LAC. Refer to the LAC card if you have one.
EBIS0007	This option is already activated.	Check that the LAC is correct for the option you want to activate.
EBIS0016	The license has already been activated for another computer.	The license has already been activated for another computer. You can deactivate the license on the other computer and then activate it on this one.

Message ID	Error message	Action
EBIS0018	You must first choose the Request File to upload.	You submitted the wrong request file, or the request file is corrupted. Try submitting a different request file. If the error occurs again, try regenerating the request file.
EBIS0025	Unable to activate license: Error Code <number>	An error occurred on the Fiery licensing server. Contact technical support and provide the error code shown in the message, the LAC, and the serial number of your Fiery server.
EBIS0002	The Fiery licensing service is unavailable. Try again later.	The Fiery licensing service is unavailable. Try again later.
EBIS0006	The License Activation Code (LAC) cannot be activated. Check that the feature(s) activated by the LAC are correct for your product.	Check that the feature(s) activated by the LAC are correct for your Fiery server model.
EBIS0011	Your system does not support some of the features included in this option. Do you want to continue?	The LAC activates multiple features, and one or more features are not supported, as shown in the list. Obtain a new LAC that has only features that are supported. If you continue, you cannot use any unsupported features, and you cannot use the LAC again.
EBIS0008	Some features of this option are already activated. Do you want to continue?	The LAC activates multiple features, and one or more features are already activated, as shown in the list. Obtain a new LAC with features that have not already been activated. If you continue, you will be paying twice for the same feature.
EBIS0026	Unable to deactivate license: Error Code <number>	Try to restore Fiery options and deactivate them again. If the error still occurs, contact technical support and provide the error code shown in the message.
EBIS0024	Unable to reactivate license: Error Code <number>	Try to restore Fiery options and reactivate them again. If the error still occurs, contact technical support and provide the error code shown in the message.
EBIS0027	No licenses have been previously activated on this computer, so you cannot restore any licenses.	Licenses have not been previously activated on this computer, so you cannot restore any licenses.