
















Installation




Fiery NX Station LS
















29





30




HDMI




HDMI - HDMI



DP

DP - DP





34

