

# Grando GD-1301, GD-1304

Grando GD-1301, GD-1304 are proof / photo printers using water-based ink.

This document provides information on how to drive the printers from Fiery XF.

# Installation requirement:

- Fiery XF 8.0.4
- Fiery Command WorkStation 7.1.0.157 or higher

# **Supported printers**

The following drivers exist:

Printer model	
Grando GD-1301	
Grando GD-1304	

### License

All Grando Models are supported by Printer Option Group 4 license

## Setting up the printer in Fiery XF

Set up the export path in Server Manager to generate a \*.prt file which you can load into the Grando Printer software.

	_
NEW PRINTER	×
Connection type	
File output $\checkmark$	
Export path	
C:\ProgramData\EFI\EFI XF\Server\Export\GrandoGD1301 Choose	
Naming	
%order_%job_%jobid_%t_%p_%date v i	
Example: 001_FileName_1_T1_P1_20240812172847	
•	
< <u>B</u> ack <u>F</u> inish <u>C</u> ancel	

### Settings

#### Resolutions

The driver offers 720x1200, 720x1800, 720x2400, 720x3600.

#### **Print modes**

The driver offers 2,3,4,6,8,12,16,18,24,32,36 pass print modes.

#### Dot sizes

S, M, L stands for Small, Middle, Large dot.

Color m	ode:	СМҮК	~
Dot size	8	SML	~
Screening: Smoothing level:		SML ML SL SM	
		Large Middle Small	
Dot Size	Purpose		

_			
Dot Size	Purpose		
SML	Lowest resolution or high ink medium		
ML	Higher head distance		
SL	Anti-banding measure		
SM	Middle resolution		
Large	Highest head distance		
Middle	Higher head distance, middle resolution		
Small	High resolution		

#### **Color Modes**

The driver offers CMYK, CMYKcmkk, CMYKOGcm. Standard Linearization is used.

3