

# Océ Arizona 660 XT/GT Printer Supplement

This document bridges the gap between Fiery XF documentation and Océ Arizona 660 XT/GT documentation. Refer to the documentation shipped with your printer and available for download from:

- https://www.manualslib.com/products/Oce-Arizona-660-Gt-4081106.html
- https://www.manualslib.com/products/Oce-Arizona-660-Xt-Uv-3460918.html

# Printer configuration

The printer driver supports the following printers:

Fiery XF Models	Connection type	Description
Océ Arizona 660 XT	TCP/IP	<ul> <li>This is a CMYK model driver. Only Contone data is sent to printer.</li> <li>There are no profiles for this printer and user needs to create one before printing.</li> </ul>
Océ Arizona 660 GT	TCP/IP	<ul> <li>This is a CMYK model driver. Only Contone data is sent to printer.</li> <li>There are no profiles for this printer and user needs to create one before printing.</li> </ul>

## System requirements

The system requirements are as follows:

- Windows OS
- Products based on Fiery XF 7.0 or later technology
- As license, you need XF Output Option Super Wide Format

## Configure XF output device for the first time

- 1. Turn on the printer.
- 2. In Fiery Command WorkStation, do the following:

© 2017 Electronics For Imaging

July 13, 2020 Fiery XF 7.2

- a. Right-click the server and select Server Manger.
- b. In Server Manager, click the Add button.



c. Configure the IP address and click Finish.


## Media source setup

Following options are available for media source for this model:



### Special settings

The special settings tab in these drivers have options as follows:



#### Constraints

InkSet	Options	Supported Print mode	Supported layers
Inkset: CMYK + WW	Use White	Print mode: Quality-Layered	Layer 1/2/3
Inkset: CMYK + W + V	Use White + Use Varnish	Print mode: Quality-Layered	Layer 1/2/3

